



Aruba Shores Candle Recipe

Recipe makes one 10 oz candle

Here's What You Need:
Ingredients

[464 Soy Wax](#)

[Aruba Shores Fragrance Oil](#)

[HTP Candle Wick](#)

[POURING POT](#)

[THERMOMETER](#)

[Turquoise Nature Friendly Liquid Candle Dye](#)

[Warning Labels](#)

Other Ingredients & Equipment You'll Need:

Scale

Mixing Spoon

Pot (For Double Boiler)

10 oz. Jar

Hot Glue Gun

Glue Sticks

Twine (optional cosmetic feature)



Here's How It's Done : Directions

Step 1: Prepare your jar. You will need a ten ounce jar. The fishnet wrapped jar is an optional cosmetic look. If you would like to create the fishnet look on the outside of your candle jar you can follow the tutorial here:

<https://coolcreativity.com/handcraft/make-fishnet-wrapped-mason-jar/>

Step 2: Use a hot glue gun to adhere a wick to the bottom center of the jar. The wick size will depend on the diameter of the jar. Our jar was about 2 inches in diameter. We used HTP-52.

Step 3: Weigh out 300 grams of the 464 soy wax and melt using a double boiler. Allow it to heat to 185F.

Step 4: Once your wax is melted, add 20 drops of the turquoise liquid candle dye. Stir.

Step 5: Next, while the temperature is at 185F, add 30 grams of Aruba Shores Fragrance Oil. Stir thoroughly.

Step 6: Allow the temperature to drop to 110F. Pour the candle wax into your jar.

Step 7: Allow the candle to set up before trimming the wick to ¼”.

Step 8: Add a warning label to the bottom of your candle jar. Allow the candle to cure.

We hope you enjoy your Aruba Shores Candle!

Nature's Garden is not responsible for the performance of any of the recipes provided on our website. Testing is your responsibility. If you plan to resell any recipes we provide, it is your responsibility to adhere to all FDA regulations. If there are ingredients listed in a recipe that Nature's Garden does not sell, we cannot offer any advice on where to purchase those ingredients. Also, we do not offer any advice on formulating or altering recipes.