



Endlessly In Love Scoopable Wax Recipe

Recipe makes approximately four 8 ounce jars

Here's What You Need:
Ingredients

[Joy Wax- 1 SLAB](#)

[Pillar of Bliss Wax- 10 Pounds](#)

[Endlessly in Love Fragrance Oil](#)

[AVOCADO OIL](#)

[8 oz. Clear PET JAR](#)

[White Straight Smooth Lid 70/400](#)

[THERMOMETER](#)

[Spectrum Liquid Candle Dye Color- RED](#)

[POURING POT](#)

[Embed Mold - Medium Hearts](#)

Other Ingredients & Equipment You'll Need:

Scale

Pot (for double boiler)

Mixing Spoon

Toothpick



Here's How It's Done : Directions

Total Recipe Amounts:

16 ounces Joy Wax

12 ounces Avocado Oil

2.88 ounces Endlessly in Love Fragrance Oil

3.5 ounces Pillar of Bliss Wax

Step 1: First, weigh out 12 ounces of the Joy Wax. Melt the wax using a double boiler.

Step 2: Use a toothpick to add a very small amount of the Spectrum Liquid Candle Dye and stir to incorporate.

Step 3: Then, add 2.1 ounces of the Endlessly in Love Fragrance Oil and 9 ounces of avocado oil to the melted wax. Stir to incorporate.

Step 4: As the mixture begins to cool, it will thicken. Continue to stir periodically until the temperature is around 130 degrees Fahrenheit or lower.

Step 5: Once your mixture has cooled, pour the mixture into the 4 ounce jars. Each jar will be filled about 3/4 of the way to the top of the jar. Allow this pink layer to set up before creating the next layer.

Step 6: While you are waiting for this layer to set up, prepare the heart embeds. So, weigh out 3.5 ounces of Pillar of Bliss Wax and melt the wax using a double boiler.

Step 7: Then, add 0.3 ounces of the Endlessly in Love Fragrance Oil and one drop of the red liquid candle dye to the melted wax. Stir to incorporate.

Step 8: Once your ingredients are melted and mixed, pour the red scented wax into the heart embed mold. Allow the wax embeds to set up before removing them from the mold.

Step 9: Now, you can create the second layer. Weigh out 4 ounces of Joy Wax and melt using a double boiler.



Here's How It's Done : Directions

Step 10: Then, add 0.7 ounces of the Endlessly in Love Fragrance Oil and 3 ounces of sweet almond oil to the melted wax. Stir to incorporate.

Step 11: Again, as the mixture begins to cool, it will thicken. Continue to stir periodically until the temperature is around 130 degrees Fahrenheit or lower.

Step 12: Once your mixture has cooled, pour the mixture into the jars to fill them.

Step 13: Then, place a wax heart on top of each of the filled 8 ounce jars.

Step 14: Once your wax has completely setup, place a lid on each jar and allow the scoopable wax to cure for at least 48 hours before using.

Your scoopable wax is now ready to use!

Nature's Garden is not responsible for the performance of any of the recipes provided on our website. Testing is your responsibility. If you plan to resell any recipes we provide, it is your responsibility to adhere to all FDA regulations. If there are ingredients listed in a recipe that Nature's Garden does not sell, we cannot offer any advice on where to purchase those ingredients.