



Linen Breeze Candle Recipe

Recipe makes one candle.

Here's What You Need:
Ingredients

[Joy Wax- 1 SLAB](#)
[Pillar of Bliss Wax](#)
[Linen Breeze Fragrance Oil](#)
[HTP Candle Wicks](#)
[Cream Color Block](#)
[Turquoise Color Block](#)
[POURING POT](#)
[Thermometer](#)

Other Ingredients Needed:
16 oz. Apothecary Jar
Hot Glue Gun
Hot Glue
Scale
Hand Mixer
Mixing Bowl
Ziploc Bag
Pots (for double boiler)
Clothespin Mold- flexiblemolds.com



Here's How It's Done : Directions

Total Recipe Amounts for Clothespins:

27 grams Pillar of Bliss Wax
2 grams Linen Breeze Fragrance Oil
Cream Color Block (less than 1 gram)

Total Recipe Amounts for Blue Layer:

75 grams Joy Wax
7 grams Linen Breeze Fragrance Oil
Turquoise Color Block (less than 1 gram)

Total Recipe Amounts for Cloud Topping:

325 grams Joy Wax
32 grams Linen Breeze Fragrance Oil

Step 1: First, we need to prepare our clothespins. Measure out the Pillar of Bliss and melt it using the double boiler method. Once it is melted, add a small shred of the cream color block. Stir to incorporate the colorant.

Step 2: Next, add 2 grams of the Linen Breeze Fragrance Oil. Once again, stir.

Step 3: Pour the wax into the clothespins mold. Allow them to setup completely before removing them from the mold.

Step 4: Now, we can prepare our candle jar with the wicks. Heat up the hot glue gun and a hot glue stick. Glue the bottoms of your candle wicks and press down on them in the center of your candle jar so that they adhere to the glass. Set it to the side until we need it.

Step 5: Next, we will make the bottom blue layer of the candle. Weigh out 75 grams of Joy Wax and melt it down. Then, add colorant. We used a small shred of a turquoise color block. Stir to incorporate.

Step 6: Add the Linen Breeze Fragrance Oil. Stir to blend the scent with the candle wax.

Step 7: Carefully, pour the mixture evenly into your candle jar, while keeping the wicks centered and straight. Allow this layer to set up completely.



Here's How It's Done : Directions

Step 8: Once the blue layer set up, begin making the white fluffy cloud portion of the candle. Weigh out 325 grams Joy Wax and melt it using the double boiler method once again.

Step 9: After it melts, add 30 grams of Linen Breeze Fragrance Oil. Stir.

Step 10: Allow the wax to cool off for about 15 minutes, then get your electric hand mixer ready. Whip the wax on and off until it starts looking like creamy frosting. Set it aside we will come back to it in the next step.

Step 11: Place the clothespins in the jar. You want to place them up against the jar. You will want them to be visible after the whipped topping is applied.

Step 12: Now, take the whipped wax and spoon it onto the layer of crust and around the clothespins. Fluff the topping until you are satisfied with the look. Remember to keep the wicks centered and straight during the process.

We hope you enjoy your Linen Breeze Candle!

Natures Garden is not responsible for the performance of any of the recipes provided on our website. Testing is your responsibility. If you plan to resell any recipes we provide, it is your responsibility to adhere to all FDA regulations if applicable. If there are ingredients listed in a recipe that Natures Garden does not sell, we cannot offer any advice on where to purchase those ingredients. We also do not offer any advice on formulating or altering recipes.