



Neapolitan Candle Recipe

Recipe makes one candle.

Here's What You Need:
Ingredients

[Joy Wax](#)
[Pillar of Bliss Wax](#)
[German Chocolate Cake Fragrance Oil](#)
[Strawberry Rhubarb Pie Fragrance Oil](#)
[Vanilla Insanity Fragrance Oil](#)
[Strawberries Embed Mold](#)
[CD Candle Wicks \(100 wicks\)](#)
[Spectrum Liquid Candle Dye- Green](#)
[Spectrum Liquid Candle Dye- Red](#)
[Spectrum Liquid Candle Dye- Yellow](#)
[Spectrum Liquid Candle Dye- Brown](#)
[Pouring Pot](#)
[Thermometer](#)

Other Ingredients & Equipment You'll Need:

Mixing Spoon
Stove
Scale
Pot (for double boiler)
Apothecary Jar
Toothpicks
Paper Bowl
Hot Glue Gun
Hot Glue Sticks
Pecan Mold (www.flexiblemolds.com)



Here's How It's Done : Directions

Step 1: Prepare the Strawberry Embeds: Use a double boiler to melt 2 grams of Pillar of Bliss Candle Wax. Once melted use a toothpick to add a tiny bit of green Spectrum Liquid Candle Dye. Mix to incorporate the color. Next, fill only the leaf portion of the strawberries embed mold using a disposable pipette. Then, allow this portion to setup.

Step 2: Next, prepare the red wax for the strawberries. Use a double boiler to melt 10 grams of Pillar of Bliss Candle Wax. Use a toothpick to add just a little bit of red liquid candle dye. Then, add 1 gram of the Strawberry Rhubarb Pie Fragrance Oil. Mix to incorporate the scent. Finally, use a pipette to add the melted wax into the remaining portion of the strawberry cavity. Allow them to setup. Remove them from the molds. Set them aside for now. You will need them to top your candle.

Step 3: Prepare the Pecan Embeds: Weigh out 20 grams of Pillar of Bliss Candle Wax. Then, melt the wax using a double boiler. Once melted, use a toothpick to add a tiny bit of both brown and yellow liquid candle dye.

Step 4: Prepare the First Layer of Chocolate Wax: Prior to starting, use hot glue to adhere two CD-10 wicks to the bottom of your candle jar. Then, weigh out and melt 90 grams of Joy Wax. Use a toothpick to add a tiny bit of brown Spectrum Liquid Candle Dye. Mix to blend the candle colorant.

Step 5: Then, add 9 grams of German Chocolate Fragrance Oil. Mix well to blend the ingredients. Then, pour the candle wax into the jar. Allow the wax to setup completely before moving on.

Step 6: Prepare the First Layer of Strawberry Wax: Now, using a double boiler, melt 90 grams of Joy Wax. Then, use a toothpick to add a tiny bit of the red Spectrum Candle Dye. Mix to incorporate the colorant.

Step 7: Now, add 9 grams of Strawberry Rhubarb Pie Fragrance Oil. Then, stir to blend the strawberry fragrance oil into the candle wax. Pour the candle wax into the jar, directly on top of the chocolate layer. Allow the pink wax to setup before moving on.



Here's How It's Done : Directions

Step 8: Prepare the First Layer of Vanilla Wax: Next, we will create a white vanilla layer of candle wax. So, once again, using a double boiler, melt 90 grams of Joy Wax. Once the wax has melted, add 9 grams of Vanilla Insanity Fragrance Oil. Then, stir to completely blend the fragrance oil into the wax.

Step 9: Next, pour the white wax directly on top of the pink wax. Allow this layer to setup completely before moving on.

Step 10: Next, repeat steps 4-7 to create a second layer of both chocolate and strawberry.

Step 11: Adding the White Whipped Wax: First, weigh out and melt 150 grams of Joy Wax. Once melted add 15 grams of Vanilla Insanity Fragrance Oil. Stir to incorporate the scent. Allow the scented candle wax to begin to setup. Then, begin whipping the wax to a frosting like consistency.

Step 12: Finally, place the whipped wax on top of the candle. Then, place your embeds on top.

Your Neapolitan Candle is now ready to use! Enjoy!